

Formaldehyde Sampling

Manufacturer: Earthbound Rv
Serial Number: 113
Test Date 12/17/10

NTA Asset No. 01086

Sample Number 1

Location of Sampling: Outside of Rv

Height of Sampling Inlet: 5'- 0" Above Finished Floor of Rv

Exterior Reading

Temperature

Humidity

Exterior Sample Reading

66.7	Degrees F
24.0	%
Less than 10	ppb

Sample Number 2

Location of Sampling: Inside of Rv in Living/Dining Area

Interior Reading

Temperature

Humidity

Start		Finish
63.1	Degrees F	62.8
29.9	%	25.0

Start Sampling Time

Finished Sampling Time

Elapsed time (In min.)

Sampling Time	Sample Reading
1:09 pm	00 ppb
1:39 pm	20 ppb
30 minutes	



Outside of Rv



Inside of Rv



Formaldehyde Sampling Checklist

Manufacturer:

Earthbound Rv

Serial Number:

113

Test Date

12/17/2010

Sample Number	2
Item	
1 Front door seal inspected and without defect	✓
2 Front door closed during sampling	✓
3 Window seals inspected and without defect	✓
4 Windows closed and locked during sampling	✓
5 Bath exhaust fan (On / Off)	Off
6 Range hood exhaust fan (On / Off)	Off
7 Furniture unwrapped and located in room	✓
8 Mattress unwrapped and located in bedroom	✓
9 Ceiling fan (On / Off)	N/A
10 Interior lights (On / Off)	On
11 Heating / air conditioning (On / Off)	Off
12 Kitchen cabinet doors (Open / Closed)	Closed
13 Bath cabinet doors (Open / Closed)	Closed
14 Bedroom wardrobe drawers (Open/Closed)	Closed
15 Interior doors (Open / Closed)	Open
16 MDF trim sealed	N/A
17 Countertop at kitchen sealed (Edges & Bottom)	N/A
18 Countertop at bath sealed (Edges & Bottom)	N/A

Footnotes

1. Item 16 thru 18 are not applicable due to innovative trim and countertop construction.
2. Item 9 is not applicable. Ceiling fan was not installed.